




Mjoelner



Power Amplifier







NOKIA PAMS Technical Documentation


Audio Interface









Key User Interface




Flash Memory



NOKIA PAMS Technical Documentation




Memory filter






NHM-8NX


System - Discrete Power Mangement







Charge Pump Capacitors








RF - BB Interface




SIM Reader



X38


CLK I/O
RST VCC
VCC GND

NOKIA PAMS Technical Documentation





- ✓ IACCDIF(5:0)
- RFAUX(1:0)
- SIMIF(3:0)
- → HOOKINT
- GENIO(31:0)
- → FMANT
- SLOWAD(6:0)
- \bigcirc USB_DIG(6:0)
- PUSL(3:0)
- ✓ AUDUEMCTRL(3:0)

NOKIA PAMS Technical Documentation




Discrete decoupling capacitors





Layout Diagram of BF4A - Top



Layout Diagram of BF4A - Bottom

